

GBL5.1K3



Emergency
Power Back-up



Flexible
Installation



Cost-
effective



Scalable



Peak Load
Shifting

About GBL5.1K3 battery

GBL5.1K3 battery can be installed in Parallel and Series mode, more attention should be paid for the DIP and address selection following with part 5.3.2.

About this manual

This manual is intended for the GBL5.1K3 battery, but the hybrid inverter and any other equipment is not included. The GS ENERGY hot line +86-574-65292531 and <http://www.gsmarte.com>. are both available if you want to get additional information.

Contents

1. Safety.....	3 -
1.1 Introduction Important Safety Instructions.....	3 -
1.2 Warnings in this Document.....	3 -
1.3 Battery handing guide.....	3 -
1.4 Response to emergency situations.....	4 -
1.4.1 Leaking batteries.....	4 -
1.4.2 Fire.....	4 -
1.4.3 Wet battery.....	5 -
1.4.4 Damaged battery.....	5 -
1.5 Installers.....	5 -
1.6 Scrap battery.....	5 -
1.7 Contact information.....	5 -
2. Product Introduction.....	6 -
2.1 Technical data.....	6 -
2.2 Exploded views of battery.....	7 -
2.3 Indicator and ports.....	8 -
2.4 Communication interface plat (DVC-A2 voltage)	8 -
2.5 How it works.....	9 -
2.6 Feature.....	9 -
3. Guidance for disconnection of batteries during shipment.....	9 -
4. Installation Prerequisites.....	10 -
4.1 Installation location.....	10 -
4.2 Installation requirements.....	10 -
4.3 Installation process.....	11 -
4.4 Installation materials.....	11 -
4.5 Tools.....	12 -
4.6 Safety instruments.....	12 -
4.7 Network cable.....	13 -

4.8 Storage.....	- 13 -
5. Battery Installation.....	- 14 -
5.1 Package items.....	- 14 -
5.2 Checks before installation.....	- 14 -
5.3 Installation the battery.....	- 15 -
5.3.1 Connect with 48Vdc Inverter.....	- 15 -
5.3.2 Address select of Master and Slave battery(ies) connection.....	- 17 -
5.4 Cable connections.....	- 20 -
5.4.1 Cable connection for Series connection.....	- 20 -
5.4.2 Cable connection for Parallel connection.....	- 21 -
6. Configuration.....	- 22 -
6.1 Settings for CAN /485 bus pins.....	- 22 -
7. Commissioning.....	- 23 -
7.1 Commissioning battery.....	- 23 -
7.2 Shutting down battery.....	- 23 -

1. Safety








1.1 Introduction Important Safety Instructions

This manual contains important instructions for:GBL5.1K3 battery and this manual must be followed when installing and using this product.

The product is designed and tested in accordance with international safety requirements IEC 60364, but as with all electrical and electronic equipment, certain precautions must be observed when installing and or operating the product. To reduce the risk of personal injury and ensure the safe installation and operation of the product, you must carefully read and follow all instructions, cautions and warnings in this manual.

1.2 Warnings in this Document

A warning describes a hazard to equipment or personnel. It calls attention to a procedure or practice, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the GS ENERGY equipment and or other equipment connected to the GS ENERGY equipment or personal injury.

Symbol	Description
	Caution, risk of electric shock
	Heavy enough may cause severe injury
	Keep the battery away from open flame or ignition sources
	Keep the battery away from children
	Do not dispose of the product with household waste
	Recycling
	Read this manual before installation and operation

For safety reasons, installers are responsible for familiarizing themselves with the contents of this manual and all warnings before performing installation.

1.3 Battery handing guide

- Use the battery pack only as directed.
- If the battery defective, appears cracked, broken or otherwise damaged, or fails to operate, contact the GS ENERGY hot line +86-574-65292531 immediately.
- Do not attempt to open, disassemble, repair, tamper with, or modify the battery. The battery pack is not user serviceable.

- To protect the battery and its components from damage when transporting, handle with care.
- Do not subject it to any strong force.
- Do not insert foreign objects into any part of the battery pack.
- Do not use cleaning solvents to clean the battery.
- The battery shall not be connected directly to SELV circuit.

1.4 Response to emergency situations

The GBL5.1K3 battery is designed with multiple safety strategies to prevent hazards resulting from failures. However, GS ENERGY cannot guarantee their absolute safety for uncertain situations.

1.4.1 Leaking batteries

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. Electrolyte is corrosive and contact may cause skin irritation and chemical burns. If one is exposed to the leaked substance, do these actions:

Inhalation: Evacuate the contaminated area, and seek medical attention immediately.

Eyes contact: Rinse eyes with flowing water for 15 minutes, and seek medical attention immediately.

Skin contact: Wash the affected area thoroughly with soap and water, and seek medical attention immediately.

Ingestion: Induce vomiting as soon as possible, and seek medical attention immediately.



1.4.2 Fire

In case of a fire, make sure that an ABC or carbon dioxide extinguisher is nearby and does not use water to extinguish the fire.

WARNING

The battery pack may catch fire when heated above 130°C.

If a fire breaks out where the battery is installed, do these actions:

1. Extinguish the fire before the battery catches fire.
2. If the battery has caught fire, do not try to extinguish the fire. Evacuate people immediately.

WARNING

If the battery catches fire, it will produce poisonous gases. Do not approach.

1.4.3 Wet battery

If the battery is wet or submerged in water, do not try to access it. Contact GS ENERGY hot line +86-574-65292531 or your distributor for technical assistance.

1.4.3 Wet battery

If the battery damaged, please contact GS ENERGY hot line +86-574-65292531 or your distributor for help as soon as possible, because damaged battery is dangerous and must be handled with extreme caution. Damaged battery is not suit for use and may pose a danger to people or property. If the battery seems to be damaged, return it to GS ENERGY or your distributor.

CAUTION

Damaged battery might export electrolyte or flammable gas, so contact GS ENERGY for advice and information immediately we will deal with it within 48h.

1.5 Installers

GS ENERGY Energy Storage battery is suggested installing by skilled worker or electrician. A skilled worker is defined as a people who had been trained and qualified electrician or had all of the following skills and experience:

- Knowledge of the functional principles and operation of on-grid Energy Storage systems.
- Knowledge of the dangers and risks associated with installing and using electrical devices and acceptable mitigation methods.
- Knowledge of the installation of electrical devices
- Knowledge of and adherence to this manual and all safety precautions and best practices.

1.6 Scrap battery

For scrap battery(-ies), please treat with local laws or regulations to recycle or scrap.

1.7 Contact information

Use the contacts below for technical assistance. This phone numbers is available only during business hours on weekdays.

Phone number	+86-574-65292531
Address	No.20 Meishen Road, Meilin Street, Ninghai County, Ningbo City, Zhejiang Province, China
E-mail	service@gsarte.com

2. Product Introduction


2.1 Technical data

Model		GBL5.1K3(LFP)
Total energy (kWh)		5.1kWh
Usable energy (kWh)		4.6kWh
Nominal charge/discharge power		3.0kW
Peak power(Only discharge)		6kW for 3 seconds
Constant current(Only discharge)		80A
Voltage range		48~56Vd.c
Nominal voltage		51.2Vd.c
Nominal current		60A
Max. charge voltage		57.6V
Max. recommended DOD		90%
Cells rated capacity		100Ah
Efficiency		>97%
Dimensions (W*H*D) (mm)		500*442*135mm
Weight (kg)		45kg
Operating condition		Indoor
Operating temperature (°C)	Charge	From 0~50 °C
	Discharge	From -10~55 °C
WIFI frequency range		2400MHz~2483MHz
Humidity		<60% (No condensed water)
Over voltage category		II
Cooling type		Natural cooling
Case material		Metal
Color		Black
Installation		Wall mounting/Ground Installation
IP rating		IP 20
Protective class		I
Max. connection number		8S/4P
Warranty		10 Years
Design life		>15 years
Communication		CAN/RS485
Protection mode		Dual hardware protection
Battery protection		Over-current/over-voltage/short circuit/under voltage/over temperature
Safety		Cell UL 1973
		CE
Hazardous Material Classification		9
Transportation		UN 38.3

Testing conditions based on temperature 25°C at the beginning of life.

*Total Energy/Usable Energy measured under specific conditions from 0.2C CC-CV

2.2 Exploded views of battery



2.3 Indicator and ports

There are two LED indicators on the front of the battery to show its operating status.





Table 2-1 Designations on the battery


Item	Designation	Definition
1	Running	Battery normally working without fault
2	Fault	Battery is in a warning state

2.4 Communication interface plat (DVC-A2 voltage)



SW1	DIP switch select for CAN or RS485
SW2	Resistance for communication and DIP switch for parallel or Series connection
SW3	Switch for battery's Address select
SW4 & SW5	Communication interface for battery or master battery with Inverter

2.5 How it works



2.6 Feature


The GS ENERGY GBL5.1K3 battery has following features:

- **Energy storage unit:** This battery is suit for photovoltaic system compatibility.
- **Expandability:** The battery capacity can be increased by adding another battery.

3. Guidance for disconnection of batteries during shipment

- 3.1 Cartons that have been crushed, punctured, or torn in such a way that contents are revealed shall be set aside in an isolated area and inspected by a skilled person. If the package is deemed to be not shippable, the contents shall be promptly collected, segregated, and either the consignor or consignee contacted.
- 3.2 The DC circuit of GS ENERGY GBL5.1K3 battery has been disconnected before outgoing.
- 3.3 A precautionary label had been affixed to the shipping carton to alert individuals as to the battery within the package have been disconnected; otherwise, the battery should not be transported.

3.4 We have conducted comprehensive tests to ensure the equipment they distribute around the world is safe for **shipping** transport. These products shall be handled with care and immediately inspected if visibly damaged. If the carton visibly damaged, please contact with GS ENERGY hot line +86-574-65292531 to confirm whether the battery could be used safely or not.



4. Installation Prerequisites

4.1 Installation location

Make sure that the installation location meets the following conditions:

- The building is designed to withstand earthquakes.
- Far away from the sea to avoid salt water and humidity.
- At least 2.5m far away from combustible.
- The installed location should not be access by pet and children.
- The floor is flat and level.
- No flammable or explosive materials nearby.
- Optimal ambient temperature is between 15°C and 30°C.
- Temperature and humidity stays at a constant level.
- Minimal dust and dirt in the area.
- No corrosive gases present, including ammonia and acid vapor.

The GS ENERGY GBL5.1K3 battery is rated at IP20, so the battery should be installed indoor.

If the ambient temperature is outside the operating range, battery will protect itself by shutting down. The battery optimal operate temperature is 15°C to 30°C. Frequent exposure to severe operating condition would exacerbate the performance and lifetime of the battery.

4.2 Installation requirements


For safety used of battery, please notice following notes when install:

- The installation shall be in a restricted access location/ room or in a cabinet where provides a barriers for the battery terminal.
- The maximum number of battery shall be not over 8 PCS, if the battery are connected in series, Or electric shock would happen.

- DVC class specification: DVC-C for battery terminal, DVC-A2 for all communication terminals.
- The insulation design for the battery is basic on voltage 450d.c. of OVC II and 230Va.c. of OVC III. Any connection to those greater than the design is not permitted.

4.3 Installation process

The battery should be installed according to the following flow chart. The detail installation process described in below **process**.



4.4 Installation materials

Following installation materials should be prepared by installers.

- Power cable
- Data cable
- Earth cable
- Ground wire
- Bipolar external isolator, when two or more battery systems in parallel, each of them shall have a bipolar isolator. Meanwhile, the isolator shall have ability to break the full load current.

NOTICE

Make sure that the cross-sectional area of charging cables is 25 to 35 mm².

NOTICE

A breaker between GBL5.1K3 battery and inverter was recommended to install, and the breaker's min. current should be over 150A or following with local regulations.

4.5 Tools


To install the battery pack, those following tools are probably required:




Phillips screwdriver



Torque wrench



Cable crimper




Wire clamp



Voltmeter



Tape measure



Drill



Flat-head screwdriver

In order to protect operator and installer's safety, please select and use suitable tools and measuring instruments that are certified for precision and accuracy.

4.6 Safety instruments

When dealing with the battery, following safety gears should be equipped. Installers must meet the relevant requirements of IEC 60364 or the domestic legislation and other relevant international standards.



Insulated glove




Safety goggles



Safety shoes

4.7 Network cable



If needed, the network cable should be made like that diagram. But the network cable between battery and Inverter should be made following the definition of Inverter. If available, use a LAN cable tester to check whether the cable is faulty.


4.8 Storage

If the battery is not to be installed immediately, or removed from operation and needs to be stored for a long period, please choose an appropriate location to store it.

Instructions for storage are:

- Do not stack more than 8 battery boxes.
- The temperature of battery stored recommended in the range of -20°C to 25°C.
- Do not expose to water

The battery box should be upright as shown in the following figure and not stacked upside down when storing the battery box.



If the battery needs to be stored over 3 months, the DC circuit of battery suggests to be disconnecting. Otherwise, the battery would discharge at a minimum rate and capacity degrades depended on storage time, the battery self-consumption less than 5w. And, if the battery stored over 6 months, it is suggested to connect the battery with inverter and commission the system.


5. Battery Installation

5.1 Package items

These items are included in the package.




Battery*1



Cardboard*1



User Manual



Warranty



Battery link*2



Data Cable*1


5.2 Checks before installation

There are a few things to check before installing the battery to ensure that it has no defects.

Check item 1: Check the battery voltage.

WARNING

If this checking process is executed for any reason after the battery is fully installed, make sure that the inverter is turned off or break the connection between battery and inverter while checking the battery.



Press and hold the panel button for about 4s and then release it after the two LED lights on, measure the voltage at the terminal interface with a voltmeter. If the voltage is lower than 48 V, do not use the battery and contact GS ENERGY hot line +86-574-65292531 or your distributor.

5.3 Installation the battery

NOTICE



The symbol located on the front of battery, and the earth wire between battery and inverter is compulsive for Series Connection. For Parallel connection, the earth wire was recommended to be installed.



5.3.1 Connect with 48Vdc Inverter

To prevent the battery from moving, make sure the battery fixed to a wall.

NOTICE


If the battery is installed above the floor or on a platform, make sure that the wall or platform is capable of supporting the battery's weight.

5.3.1.1 Wall mounting



1. Determine bracket mounting place to be fixed using this Positioning cardboard.
2. Drill holes in the wall for the M8 expansion screw anchors, which depth should be at least 50 mm. Tighten the screws to a torque around 2.5 N·m.
3. Fasten the battery to bracket fasten hole with M6 screws with 2.0N·m roughly.

4. Meanwhile, two or four batteries could be installed by theses brackets.




Note: if more than 4 batteries installed, a cabinet recommended to be selected for the battery's stable.


The installed location shall be restricted access or installed in a cabinet which provides a guard from pet and children.

5.3.1.2 Ground installation

Meanwhile, GBL5.1K3 battery also could be installed on floor, the installation step as following:



1. Fix the braced feet to battery's mounting holes one by one.



2. If more power and energy needed, two or more (less than 4) batteries could be installed in one stack.
3. But if the number of batteries at the range of 4~8, a cabinet recommended to be selected.



















































5.3.2 Address select of Master and Slave battery(ies) connection



WARNING

Please make sure the SW2 DIP switch selected correctly, if the battery connected in Parallel mode, but select SW2 DIP8 at ON position, probably lead serious fault even dangerous. Meanwhile, if battery connected in Series mode select SW2 DIP8 at OFF status, serious fault and dangerous probably occurred.

For Series&Parallel connection, please set the DIP switches as bellow.

Connected battery number	Group	Set of SW2		Address Set (SW3)
		Series connect	Parallel connect	
1	—			
2	Master			
	Slave			
3	Master			
	Slave 1			
	Slave 2			
4	Master			
	Slave 1			
	Slave 2			
	Slave 3			
5	Master			
	Slave 1			
	Slave 2			
	Slave 3			
	Slave 4			
6	Master			

	Slave 1			
	Slave 2			
	Slave 3			
	Slave 4			
	Slave 5			
7	Master			
	Slave 1			
	Slave 2			
	Slave 3			
	Slave 4			
	Slave 5			
	Slave 6			
8	Master			
	Slave 1			
	Slave 2			
	Slave 3			
	Slave 4			
	Slave 5			
	Slave 6			
	Slave 7			

5.4 Cable connections

WARNING


Before connecting battery with inverter, please make sure that no inverter connected or the inverter turned off.

5.4.1 Cable connection for Series connection


NOTICE

The voltage difference of each battery should be less than 100mV.

5.4.1.1 Ground installation




Feed a data cable to M/S communication terminal interface one by one directly.



If more than 4 batteries installed, a cabinet was recommended.

5.4.1.2 Wall mounting




For wall mounting, the battery Series connection number should be less than 4, if more batteries installed, a cabinet was recommended.

NOTICE

If battery connected in Series mode, it's better to be installed in Ground installation method, for the Power cable resistance difference between stack and battery pack, which will have fade effect on voltage balance.


5.4.2 Cable connection for Parallel connection

5.4.2.1 Ground installation





For parallel installation, please pay attention on Cable connection, and the DIP8 of SW2 no need to be changed and stayed on Initial Factory state.

5.4.2.2 Wall mounting



For wall mounting, the battery Series connection number should be less than 4, if more batteries installed, a cabinet was recommended.



NOTICE

Before two or more batteries installed in parallel, please check the voltage of each battery and make sure the voltage different less than 2.0V.

6. Configuration

SW1, SW4 and SW5 should be set correctly for proper communication between inverter and battery.

6.1 Settings for CAN /485 bus pins



SW1: For CAN communication, please set pin1 and pin2 at on, pin3 and pin4 at off
For 485 communication, please set pin1 and pin2 at off, pin3 and pin4 at on

SW4, SW5: Please use them to set the port of RJ45

Low signal (CAN) / B (485)--SW4

High signal (CAN) /A (485)--SW5

Example (above picture): CAN communication, port 5 of RJ45 is low signal, port 4 of RJ45 is High signal.

NOTICE

The battery default protocol is CAN bus, if an inverter communication mode is RS485 or other protocol, please contact GS ENERGY hot line +86-574-65292531 before installed the battery.

7. Commissioning

7.1 Commissioning battery

If there is only one battery installed, use the following steps to put it in operation:

1. Press and hold the panel button on the left side of the unit for about 5s, after the indicator lights on, release the panel button.
2. Make sure that the Run light is on. If it stays off, do not use the battery and contact GS ENERGY +86-574-65292531 or your distributor.
3. Turn the inverter on, and wait for the start-up sequence to complete fully.

When there are two or more batteries connected with parallel mode, after the charging cable and the data cable has been connected correctly, follow these steps to put them in operation:

1. Check battery voltage level is above 48V
 - a) If battery voltage is under 45V contact your distributor or GS ENERGY after service hot line for help.
2. Press and **HOLD** the panel button for about 4s, then the indicator lights will turn on.
3. Release the panel button.
 - a) For all batteries, make sure that the Run light is on.
 - b) Make sure the maximum voltage different between batteries less than 2.0V.
 - c) If not, the installer should balance the battery voltage and then parallel connect batteries together.
 - d) Set the DIP switches like part **6-1 Setting for communication interface**.
4. Turn the inverter on, and wait for the start-up sequence to complete fully.

7.2 Shutting down battery

1. Press and hold the Panel Button about 5s, after a disconnect voice of relay come can release it.
2. Make sure that every light on the battery is off.